







TCM

- The TCM detects the vehicle conditions and performs calculations and processing based on input information from each type of sensor and switch.
- Outputs control signals to each solenoid valve so that each type of control is optimally implemented according to the vehicle conditions.

FRONT HARNESS
ENGINE HARNESS
ENGINE No.2 HARNESS
REAR HARNESS
INSTRUMENT PANEL HARNESS
EMISSION HARNESS

